Body Dimensional Drawings

Upper Body Measuring Dimensions
- Engine Compartment 6-2
- Passenger Compartment 6-3

Engine/Transmission Mounting Position 6-3

Under Body Measuring Dimensions
- Sedan 6-4
- Coupe 6-5

Opening Repair Chart
- Sedan 6-6
- Coupe 6-7

Frame Repair Chart
- Sedan, all except V-6 engine model 6-8
- Sedan, V-6 engine model 6-12
- Coupe, all except V-6 engine model 6-16
- Coupe, V-6 engine model 6-20